



CARING FOR GROUT A HOMEOWNER'S GUIDE

Thank you for choosing SPECTRALOCK® PRO Premium Grout for your installation. Please follow the guidelines below to keep your installation looking beautiful and clean.

LATICRETE® SPECTRALOCK® PRO Premium Grout is stain resistant when correctly installed and allowed to cure properly, which is typically up to 14 days after installation. With proper care and maintenance, SPECTRALOCK PRO Premium Grout can almost always be cleaned back to its original colour.

Routine maintenance and regular cleaning of spills is required to ensure long-term beauty of the installation. For all cleaning purposes we recommend the LATICRETE STONETECH® care range of pH-neutral cleaners. LATICRETE epoxy grout requires regular cleaning with pH neutral cleaners like STONETECH Stone & Tile Cleaner, which may differ from the cleaning requirements of the floor or wall finish.

Please consult the cleaning requirements of the surface finish manufacturer before cleaning. Before using any cleaning product, test a small, inconspicuous area and allow to dry completely to test compatibility, and test any scrubbers to ensure they don't scratch soft or polished surfaces.

Please avoid highly alkaline, acidic ammonia based, abrasive cleaners, and bleach.

Maintenance Cleaning Procedure

For routine, everyday cleaning, a clear pH neutral cleaner such as STONETECH Stone & Tile Cleaner is recommended.

Some floor cleaning procedures such as damp mopping will deposit dirt residue on the LATICRETE surface finish. In this case, mop a solution of STONETECH Stone & Tile Cleaner onto the surface and gently agitate with a brush or scrub pad. Rinse well, vacuum, and allow to dry.

Spills & Stains Cleaning Procedure

Wipe spills immediately with a cloth or paper towel. If stain remains, scrub for 60 seconds with warm water and a white nylon scrubbing pad.

- For **soiling from grease**, use a gentle alkaline cleaner such as STONETECH KlenzAll™.
- For **hard water deposits** and other **inorganic stains**, use STONETECH RESTORE™ Acidic Cleaner.
- For **soap scum** removal, use STONETECH Soap Scum Remover.
- For **mold and mildew** removal use STONETECH Mold & Mildew Stain Remover.



Scan for detailed cleaning information



Please consult the TDS and MCI for all products and surfaces before applying



Find your nearest STONETECH supplier



For further support, contact LATICRETE Australia
1800 331 012 | www.laticrete.com.au | sales@laticrete.com.au