

# Globally Proven Construction Solutions

## **4237 Latex Additive**

4237 Latex Additive is a specially designed latex additive for use with 211 to make a high strength latex thin bed and medium bed adhesive up to 15 mm. For installing all types of tile, stone and agglomerates.

Also for use with Portland cement to make slurry bond coats for mortar beds and for use with thin set adhesives to give improved performance and longer open time. To achieve longer open time under tropical or desert conditions, the use of LATICRETE Thin-Set Adhesive 315 Adhesive is recommended instead of 211.





## FEATURES/BENEFITS

- Superior bond strength.
- Flexible and shock resistant; rated for extra heavy traffic conditions.
- Weather and frost resistant for interior and exterior use in all types of climates.
- Proven performance; used in all types of applications for over 60 years.
- Safe, economical and easy to use; non-hazardous, non-flammable.

## PACKAGING

- 20 litre pail; 32 pails per pallet
- 5 liter jerrycan; 3 jerrycans per carton

## USES

Used for installation of all types of ceramic tile, brick, natural stone and agglomerates. 4237 Latex Additive offers the speed and economy of adhesives with the permanent, water resistant dependability of Portland cement. Can also be mixed with PERMACOLOR® Grout to make coloured adhesive for the installation of paper face mounted glass mosaic tiles.

## **SUITABLE SUBSTRATES**

- Concrete
- Cement terrazzo
- Brick masonry
- Cement plaster
- Concrete masonry
- Cement backer board\*
- Cement mortar beds
- Ceramic tile and stone
- Gypsum wallboard (interior only)
- \*\* Consult cement backer board manufacturer for specific installation recommendations and to verify acceptability for exterior use.

## **MANUFACTURER**

LATICRETE Australia Pty Ltd 29 Telford Street Virginia, QLD 4014 Australia

Telephone: 07 3865 1599
Toll Free: 1800 331 012
Fax: 07 3865 2250
Internet: www.laticrete.com.au

<sup>^</sup> United States Patent No.: 6,784,229 (and other Patents).

#### **Approximate Coverage**

- Per 20 litre pail of 4237 Latex Additive when mixed with 80 kg of 211.
- $26 31 \text{ m}^2 \text{ using a 6 mm x 6 mm square notched trowel}$
- $19 24 \text{ m}^2$  using a 6 mm x 9 mm square notched trowel

#### **Shelf Life**

Factory sealed containers of this product are guaranteed to be of first quality for two (2) years if stored indoors and off the ground at temperatures  $>0^{\circ}$  C and  $<43^{\circ}$  C.

#### Limitations

- Use LATAPOXY® 300 Adhesive for installing green marble or water sensitive natural stone and agglomerates.
- Use a white thin set adhesive when installing white or light coloured natural stone.
   Adhesives/mastics, mortars and grouts for ceramic tile, pavers, brick and stone are not replacements for waterproof membranes. When a waterproofing membrane is required, use a LATICRETE Waterproofing Membrane.
- Note: Surfaces must be structurally sound, stable and rigid enough to support ceramic/stone tile, thin brick and similar finishes. Substrate deflection under all live, dead and impact loads, including concentrated loads, must not exceed L/360 for thin bed ceramic tile/brick installations, L/720 for ceramic tile/brick to external framed and sheeted substrates or L/720 for thin bed stone installations where L=span length.

#### Cautions

- Consult SDS for more safety information.
- During cold weather, protect finished work from traffic until fully cured.
- Wait 14 days after the final grouting before filing water features with water at 21°C.
- Keep out of reach of children.

#### **TECHNICAL DATA**

When mixed with 315 Adhesive, meets and exceeds the requirements of AS ISO13007 - 2013 as a CZTES2.

When mixed with 211, meets and exceeds the requirements of AS ISO13007-2013 as a C2ES1 adhesive.

LATICRETE 211 gauged with 4237 Latex Admix when tested over HYDRO BAN in accordance with AS ISO 13007.5-2020 meets the requirements of classification DM P.

## VOC

Green Building Council of Australia Green Star Office Design V3 IEQ-13 37 grams/litre as VOC content per coating.

#### **Performance Properties**

4237 Latex Additive mixed with 315 Adhesive

Test	Test Method	Result
28 day Tensile Strength	AS ISO 13007.1 & 2	>3MPa
Water immersion	AS ISO 13007.1 & 2	>1.4MPa
Heat Ageing	AS ISO 13007.1 & 2	>3MPa
30 minute open time	AS ISO 13007.1 & 2	>2.5MPa
Transverse Deformation	AS ISO 13007.1 & 2	>5.5mm

4237 Latex Additive mixed with 211 at 21 °C.

Test / Test Method	Results	
Shear Bond, Porcelain Tile, 28 day cure	2.76—4.14 MPa	
ANSI A118.4 5.2.4		

Shear Bond, Porcelain Tile, Water Immersion ANSI A118.4 5.2.3	2.2—2.48 MPa
Shear Bond, Porcelain Tile, 7 day cure ANSI A118.4—5.2.2	2.4—2.55 MPa
Water Absorption ANSI A118.6—4.4	<4%
Compressive Strength ANSI A118.4—6.1	34.5 MPa
TCA Service Rating ASTM C-627	Extra Heavy
Tensile Bond BS 5980:1980 Class AA; 14 days	1575 N (161 kg)
Shear Adhesion BS 5980:1980 Class AA; 14 days	22.8 kN (2325 kg)
Coefficient of Linear Thermal Expansion ASTM C-531	117 x 10-7/(°C)

#### **Working Properties**

4237 Latex Additive mixed with 211 at 21°C

PROPERTY	VALUE
Open Time	30 minutes
Pot Life	5 hours
Time to Light Traffic @ 21°C	24 hours
Average Wet Density	1700 kg/m³

Specifications subject to change without notification. Results shown are typical but reflect test procedures used. Actual field performance will depend on installation methods and site conditions.

## **INSTALLATIONS**

Unless otherwise noted in this document all work shall be in accordance to AS3958-2023.

## **Surface Preparation**

All surfaces should be between 4 °C and 32 °C and structurally sound, clean and free of all dirt, oil, grease, loose peeling paint, concrete sealers or curing compounds. Rough or uneven concrete surfaces should be made smooth with LATICRETE Latex Portland Cement underlayment to provide a wood float (or better) finish. Dry, dusty concrete slabs or masonry should be dampened and excess water swept off. Installation may be made on a damp surface. Note: Latex Portland Cement Mortars do not require a minimum cure time for concrete slabs. For tiles that have a length of  $<\!\!380 \text{mm}$  substrates must be plumb and true to within 5mm in 3m and 1.5mm in 600mm when measured from the high spot for thin-set installations. For tiles that have a length of  $>\!\!380 \text{mm}$  substrates must be plumb and true to within 3mm in 3m and 1.5mm in 300mm when measured from the high spot. Movment joints shall be provided through the tile work from all construction or movement joints in the substrate. Follow the Australian Standards requirements for movement joints in AS 3958 or TCNA detail EJ-171 "Movement Joints — Vertical & Horizontal". Do not cover movement joints with adhesive.

#### **Mixing**

Stir 4237 Latex Additive thoroughly before use.

Use approximately 4.5-5.5 litres of 4237 Latex Additive to 20 kg of 211, or approximately 5-5.4 litres of 4237 Latex Admix to 20kg of 315 Super Floor & Wall Adhesive. Place 4237 Latex Additive in a clean plastic pail. Do not dilute. Add 211 to 4237 Latex Additive and mix to a smooth, trowelable consistency. Allow adhesive to slake for 5-10 minutes. Adjust consistency if necessary. Remix and apply with the proper sized notched trowel. **Note:** For the installation of paper-face mounted glass mosaic tile, mix approximately 2.5 litres of 4237 Latex Additive with 10 kg of PERMACOLOR® Grout.

#### Application

Apply adhesive to the substrate with the flat side of the trowel, pressing firmly to work into surface. Comb on additional adhesive with the notched side. **Note:** Use the proper sized notched trowel to insure full bedding of the tile. It is essential that enough adhesive is used to completely cover the back of the tile with a minimum 2 mm to 3 mm uniform thickness. Spread as much adhesive as can be covered with tile in 15-20 minutes. Back butter large tiles >200 mm x 200 mm to provide full bedding and firm support. Place tiles into wet, sticky adhesive and beat in using a beating block and rubber mallet to imbed tile and adjust level. Check adhesive for complete coverage by periodically removing a tile and inspecting bedding adhesive transfer onto back of tile.

#### Grouting

Grout after a minimum of 24 hours curing at 21°C using PERMACOLOR® Select Grout; PERMACOLOR Grout; or, PERMACOLOR NS Grout. For greater stain & chemical resistance use SPECTRALOCK PRO Premium Grout or other LATAPOXY Grouts. For further information see TDS1400.

#### **Slurry Bond Coats**

Mix in the ratio of 20 litres of 4237 Latex Additive with  $1.5 - 2 \times 20 \text{ kg}$  bags of 211 with a high speed mixer to make a smooth creamy slurry bond coat for use on suitable surfaces under mortar beds. Do not allow slurry bond coat to skin or dry prior to the application of the mortar bed. See TDS1009 for further information.

#### **Cold Weather Note**

The setting of Portland cement mortars, adhesive and grouts are retarded by low temperatures. Protect finished work for an extended period when installing in cold weather. For faster setting adhesive use a LATICRETE® Thin-Set with 4237 Rapid Latex Admix. Do not set tile when surface temperature is below freezing or when substrate is frozen. See TDS 1175 for further information

#### **Hot Weather Note**

The evaporation of moisture in Portland cement mortars and adhesives is accelerated by hot, dry conditions. Apply to dampened surfaces and protect freshly spread adhesive and finished work when installing in temperatures over 35 °C. See TDS1018 for further information.

### Cleaning

Clean tools and tile work with water while adhesive is fresh.

#### **AVAILABILITY AND COST**

#### **Availability**

LATICRETE and LATAPOXY® materials are available worldwide.

For Distributor information: Toll Free: 1800 331 012 Telephone: 07 3865 1599

For online distributor information, visit LATICRETE at www.laticrete.com.au

#### Cost

Contact a LATICRETE Distributor in your area.

#### **MAINTENANCE**

LATICRETE and LATAPOXY grouts require routine cleaning with a neutral pH detergent and water. All stone and tiles should be maintained and sealed with STONETECH® products as appropriate for the specific tile / stone and installation situation.

All other LATICRETE and LATAPOXY materials require no maintenance but installation performance and durability may depend on properly maintaining products supplied by other manufacturers.

#### **TECHNICAL SERVICES**

#### Technical assistance

Information is available by calling:

Toll Free: 1800 331 012
Telephone: 07 3865 1599
Fax: 07 3865 2250

#### Technical and safety literature

To acquire technical and safety literature, please visit our website at

www.laticrete.com.au

#### **DISCLAIMER**

- The information contained in this document is given in good faith and to the best of our knowledge is true and accurate.
- This information is subject to change without notice and it is the responsibility of the
  user to obtain up to date and current information.
- The use of this product is beyond our control and liability is assumed by the user when
  used incorrectly and not in accordance with LATICRETE guidelines.
- The manufacturer is not responsible for any loss or damage arising from incorrect usage
  of this product.
- The specifier or other party responsible for the project must ensure that the details in this
  data sheet are appropriate for the intended application and that additional detailing is
  performed for specific design or any areas that fall outside the scope of this specification.

## **LATICRETE Australia Pty Ltd**

29 Telford Street, Virginia QLD 4014 Australia

1800 331 012 www.laticrete.com.au

<sup>^</sup> United States Patent No.: 6,784,229 (and other Patents).

<sup>&</sup>lt;sup>†</sup> United States Patent No.: 6,881,768 (and other Patents).