

# HYDRO BAN®

HYDRO BAN is a thin, load bearing waterproofing/crack isolation membrane. A single component self-curing liquid rubber polymer that forms a flexible, seamless waterproofing membrane. HYDRO BAN bonds directly to a wide variety of substrates.





# FEATURES/BENEFITS

- Allows for flood testing in 24 hours\*
- Bonds directly to metal and PVC plumbing fixtures
- Thin, only 0.5mm 0.8mm thick when cured.
- Changes in color from a light sage to an olive green when cured.
- Anti-fracture protection of up to 3mm over shrinkage and other non-structural cracks.
- "Extra Heavy Service" rating per ASTM C627 "Robinson Floor Test".
- Exceeds ANSI A118.10 and A118.12
- IAPMO approved containing anti-microbial protection.
- Equipped with anti-microbial technology.
- Safe—no solvents and non-flammable
- Install tile, brick, and stone directly onto membrane.
  - \* Will cure at 24°C or higher at 50% RH, lower temperature at higher RH will require longer curing time

# MANUFACTURER/DISTRIBUTED BY

LATICRETE Philippines, Inc. Lot 9A, Manggahan Industrial Park, Brgy. Manggahan, Sta. Maria, Bulacan 3022

Telephone: +632 8656 6118 Email: info@laticrete.ph Internet: ph.laticrete.com

# USES

- Interior and exterior
- Swimming pools, fountains, and water features
- Shower pans, stalls, and tub surrounds.
- Industrial, commercial, and residential bathrooms and laundries
- Spas and hot tubs
- Kitchens and food processing areas
- Terraces and balconies over unoccupied spaces.
- Countertops and facades.
- Steam rooms (when used in conjunction with a vapor barrier)

# STANDARDS/CERTIFICATIONS

- ASTM D412
- ASTM D4541
- ASTM C836
- ASTM D2240
- DIN 1048



This product has been certified green under Singapore Green Building Council.

#### Suitable Substrates

- Concrete
- Cement mortar beds
- Cement plaster
- Self-leveling underlayment
- Ceramic tile & stone\*
- Cement terrazzo\*
- Drvwall board\*\*
- \* This type of substrate should be laid with LATICRETE latex Thin-Set Mortar prior to application
- \*\*Consult cement backer board manufacturer and LATICRETE Technical Department for specific installation recommendations and to verify acceptability for exterior use

## **Packaging**

Commercial Unit: 25kg pail liquid (36 commercial units/pallets)

# **Approximate Coverage**

25kg of HYDRO BAN yields approximately 24m² per 2 coats.

#### Shelf Life

Factory sealed containers of this product are guaranteed to be of first quality for two (2) years if stored at temperatures >0°C and <40°C.

#### Limitations

- DO NOT bond to particle board, Luan, Masonite, or hardwood surfaces.
- DO NOT use over dynamic expansion joints, structural cracks, or cracks with vertical differential movement.
- **DO NOT** use over cracks >3mm in width.
- DO NOT use as a vapor barrier (especially in steam rooms.)
- DO NOT expose to negative hydrostatic pressure, excessive vapor transmission, rubber solvents or ketones.
- DO NOT expose unprotected membrane to sun or weather for more than 30 days.
- Must be covered with ceramic tile, stone, brick, concrete, screeds, terrazzo, or other traffic-bearing finish. Use protection board for temporary cover.
- Consult technical service if to be used as a primary waterproofing membrane over occupied space.

Note: Surfaces must be structurally sound, stable, and rigid enough to support ceramic/stone tile, thin brick, and similar finishes. Substrate deflection under all live, dead and impact loads, including concentrated loads, must not exceed 1/360 for thin bed ceramic tile/brick installations or 1/480 for thin bed stone installations where I=span length.

## **TECHNICAL DATA**

# **Physical Properties**

Test	Test Method	Results
Tensile Strength (3 days)	ASTM D412	> 2.7N/mm2
Tensile Strength after Heat Aging	ASTM D412	> 4.7N/mm2
Adhesion Strength	ASTM D4541	>2.4N/mm2
Elongation at Break	ASTM D412	> 500%
Crack Bridging	ASTM C836	No cracks at 2mm
Resistance to water penetration (mm)	DIN 1048	0
Shore AHardness	ASTM D2240	>76

#### **Cautions**

Consult MSDS for more safety information.

- During wet weather, protect finished work until fully cured.
- May irritate eyes and skin. Avoid contact with eyes or prolonged contact with skin. In case of contact with water.
- Do not take internally.
- Keep out of reach of children.
  - \*Specifications subject to change without notification. Results shown are typical but reflect test procedures used. Actual field performance will depend on the type of tile/stone/brick used, installation methods and site conditions.

## **Working Properties**

HYDRO BAN can be applied using a paint brush, roller, airless sprayer, or trowel. All areas must have two coats to ensure waterproofing capabilities. When using a paint roller, substrate will not show through HYDRO BAN if coated at 0.5-0.8 mm of dry thickness. The color changes from a light sage to olive green when fully cured.

#### INSTALLATION

#### **Surface Preparation**

Surface temperature must be 8-35°C during application and for 24 hours after installation. All substrates must be structurally sound, clean, and free of dirt, oil, grease, paint, laitance, efflorescence, concrete sealers or curing compounds. Make rough or uneven concrete smooth to a wood float or better finish with a LATICRETE underlayment. Do not level with gypsum or asphalt-based products. Pre wet hot or dry surfaces and sweep off excess water. New concrete slabs shall be damp cured and a minimum of 14 days old before application.

#### Pre-Treat Cracks, Joints, Coves/ Corners & Backer Board Joints

Fill all substrate cracks, cold joints, coves/ corners & Backer Board Joints with a liberal coat of HYDRO BAN approximately 200mm wide using a paint brush or roller (heavy napped roller cover). Fold 15cm wide LATICRETE Waterproofing/ Reinforcing Fabric in half. Lay it into the coat of wet HYDRO BAN and smooth out any wrinkles. Flash LATICRETE Waterproofing/ Reinforcing Fabric 75mm up walls and other vertical surfaces. Press down on LATICRETE Waterproofing/ Reinforcing Fabric with brush or roller until liquid "bleeds" through from below. When the first coat has dried to a uniform olive-green color, apply the second liberal coat of to seal reinforcing liauid membrane LATICRETE Waterproofing/ Reinforcing Fabric.

Installer must verify that deflection under all live, dead and impact loads of interior plywood floors does not exceed industry standards of L/360 for ceramic tile and brick or L/480 for stone installations where L=span length.

#### **Pre-Treat Penetrations**

Allow for a minimum 3mm space between drains, pipes, lights or other penetrations and surrounding ceramic tile, stone, or brick. Pack any gaps around pipes, lights, or other penetrations with a LATICRETE Latex fortified thin-set mortar. Apply a liberal coat of HYDRO BAN liquid around penetration opening. Embed 150 mm LATICRETE Waterproofing/ Reinforcing Fabric and then apply a second coat of HYDRO BAN. Bring HYDRO BAN up to level of tile or stone. When dry, seal flashing with Latasil.

#### Protection

Provide protection for newly installed membrane, even if covered with a thin bed ceramic tile, stone, or brick installation, against exposure to rain or other water for a minimum of 24 hours at 21°C and 50% RH.

#### Mixing

Use direct from pail.

# **Application**

Allow any pre-treated areas to dry to the touch. Apply a liberal coat of HYDRO BAN with brush or roller over substrate including pre-treated areas. Apply another liberal coat of HYDRO BAN over the first coat of HYDRO BAN. Let topcoat dry to the touch, approximately 1-3 hours\* at 21°C and 50% RH. When the last coat has dried to the touch, inspect the final surface for pinholes, voids, thin spots, or other defects. HYDRO BAN will dry to an olive-green color when fully cured. Use additional HYDRO BAN to seal defects. \*The curing time will greatly vary depending on substrate, temperature, and relative humidity.

# **Installing Finishes**

Allow HYDRO BAN to dry for 24 hours before ceramic tile, stone or brick may be installed by the thin bed method with a LATICRETE Latex Thin- Set Mortar. Allow HYDRO BAN to cure 24 hours at 21°C and 50% RH before covering with concrete, thick bed mortar, screeds, toppings, coatings, epoxy adhesives, terrazzo, or moisture sensitive resilient or wood flooring. Do not use solvent-based adhesives directly on HYDRO BAN.

## **Expansion Joints**

Ceramic tile, stone and brick installations must include expansion at coves, corners, other changes in substrate plane and over any expansion joints in the substrate. Expansion joints in ceramic tile, stone or brickwork are also required at perimeters, at restraining surfaces, at penetrations and at the intervals described in the Tile Council of North America (T(NA) Handbook Installation Method EJI 71. Use Latasil and backer rod.

# Spray Application of HYDRO BAN

Follow all installation and surface preparation requirements outlined in this document and DS 663.5 and TDS 410.

The sprayer being used for the application of HYDRO BAN should be capable of producing a maximum of 22.8MPa with a flow rate of 0.95 to 1.6 GPM (3.6 to 6.0 LPM) using a 0.521 or a 0.631 reversible tip. Keep the unit filled with HYDRO BAN to ensure continuous application of liquid. The hose length should not exceed 30m min length and 9 mm in diameter.

Apply a continuous HYDRO BAN film with an overlapping spray. The wet film has a sage green appearance and dries to a darker olive-green color. When the first coat has dried to a uniform olive-green color, approximately 45 to 90 minutes at 21°C, visually inspect the coating for any voids or pinholes. Fill any defects with additional material and apply the second coat at right angles to the first. The wet film thickness should be checked periodically using a wet film gauge. Each wet coat should be 0.4-0.6 mm thick. The combined dried coating should be 0.5-0.8 mm thick.

# Cleaning

While wet, HYDRO BAN can be washed from tools with water.

#### **AVAILABILITY AND COST**

Availability

LATICRETE and LATAPOXY materials are available worldwide.

 $For \ distributor \ information, \ call:$ 

Telephone: +632 8656 6118

For on-line distributor information, visit LATICRETE at

ph.laticrete.com

# Cost

Contact a LATICRETE Distributor in your area.

#### WARRANTY

LATICRETE Philippines Inc. warrants that LATICRETE HYDRO BAN is free from manufacturing defects and will not break down, deteriorate, or disintegrate under normal usage for a period of one (1) year from date of purchase subject to the terms and conditions stated.

#### **MAINTENANCE**

LATICRETE® and LATAPOXY® grouts require routine cleaning with a neutral pH cleaner (e.g. STONETECH® Stone & Tile Cleaner) and water. All other LATICRETE and LATAPOXY materials require no maintenance, but installation performance and durability may depend on properly maintaining products supplied by other manufacturers.

#### TECHNICAL SERVICES/CONTACT

Technical Assistance Information is available by calling:

LATICRETE Philippines, Inc. Lot 9A, Manggahan Industrial Park, Brgy. Manggahan, Sta. Maria, Bulacan 3022 Telephone: +632 8656 6118

Email: info@laticrete.ph

Technical and Safety Literature
To acquire technical and safety literature, please visit our website
at ph.laticrete.com