



Globally Proven  
Construction Solutions

# Sealed Stone Testing and Treatment

## TDS-1261

Determining if a stone is sealed is an important question which must be answered prior to considering the application of a new sealer treatment. Realizing if an unsealed stone surface will be able to accept a sealer is also important in determining how to move forward. There is a very simple and inexpensive test to determine if the stone, Saltillo tile or cement-based grout is currently sealed, or if it even requires a sealer.

### Water Test:

The quick and easy test is performed with water and can provide valuable information about the current state of the stone or grout surface.

1. Apply water in a few different areas of the stone and/or grout
2. Make each application of water approximately 25mm wide
3. Roughly measure the size of the circle of water without making contact with the water. Make a notation as to the size of each application of water
4. Place a drinking glass over each application of water to protect from evaporation
5. Let sit undisturbed for 20 min
6. After 20 Min remove the glass(es) and observe the results
  - A. *No Change* - If the water appears the same as when it was applied and the water measures the same diameter, then a sealer is already present or the stone is very dense and does not need a sealer. In fact, a very dense stone may not accept a sealer (since absorbency is necessary for a material to accept a sealer).
  - B. *Slight Change* - If the water is still present in a bead but appears to be absorbing into the surface then a sealer may already be present but requires resealing, or, the stone is not sealed and is dense enough to allow for the slow absorption of water
  - C. *Complete Change* - If the water is completely absorbed into the surface and the spot appears to have grown in size then the stone is not sealed and the use of a high quality sealer (e.g. STONETECH® BULLETPROOF®, STONETECH® Heavy Duty Sealer, STONETECH® IMPREGNATOR PRO® Sealer, etc...) is strongly recommended.

### Benefits of Testing:

Sealers are important to provide water and oil repellency to the surface of the stone, Saltillo tile or cement-based grout. Performing the water test will not only help to determine if a sealer is present or required, it can also provide good information as to how many coats of sealer may be necessary.

As stated above, if water is repelling on the substrate and is not darkening or penetrating into the stone then a sealer will most likely not be necessary. If the owner would like a non-sealed, dense stone treated with a sealer then a solvent-based impregnating sealer (e.g. STONETECH IMPREGNATOR PRO Sealer) would be the best choice and only one coat may be necessary.

If the surface is absorbing the water, but slowly, it either means that the stone is fairly dense and no sealer is present, or, that a sealer is present but may require reapplication. If the owner is not aware of the presence of a previously applied sealer then it may be necessary to perform another test. Use STONETECH® KLENZALL™ to remove existing sealers in a small inconspicuous area and perform the water test again. If the water absorbs more quickly then it will be necessary to remove the old sealer on the entire surface prior to applying the new sealer. If there is no change in the absorption of water in the test area then a sealer was most likely not present and sealer application can commence. This type of stone may require 2 coats of sealer, but check the product data sheet of the sealer for more specific application guidelines and for compatibility for the specific surface being sealed. Please contact LATICRETE Technical Services at 1800 331 012 or visit [www.laticrete.com.au](http://www.laticrete.com.au) for more information.

If the water is penetrating quickly into the surface then 2 conditions exist; there is no sealer present and the surface is highly absorptive. It is strongly recommended that this stone be sealed prior to exposure water, oil or any other damaging effects. This type of stone may require 2 or more coats of sealer, so it is important to check the product data sheet of the sealer for more specific application guidelines and for compatibility for the specific surface being sealed. Please contact LATICRETE Technical Services at 1800 331 012 or visit [www.stonetech.com](http://www.stonetech.com) for more information.

It is important to note that not all types of natural stone and grouts have the same absorbency or physical characteristics (e.g. polished, honed, flamed, etc...). Knowing this, it is extremely important to use the correct sealer for the type of stone being sealed and for its intended use and exposure. Failing to do so, may lead to some unexpected results which may have an impact on the final appearance and performance of the stone.

Please note that porcelain and glazed ceramic tile are impervious to staining and do not require sealing. However, stone, porcelain and ceramic tile do require cleaning so please visit [www.laticrete.com.au](http://www.laticrete.com.au) for more information.

### Recommendations for Sealer Removal:

To get the maximum benefits of the STONETECH sealer it is important that the stone or grout absorb all of the components of the sealers. If pre-existing sealers are present then the successful transfer of all ingredients of the sealer into the surface may be inhibited, which can lead to some issues with the stain-resisting capabilities of the sealer.

If testing has determined that the stone may have an existing sealer present then it will be necessary to remove them prior to application of a new sealer.

1. If the existing sealer is a penetrating type (e.g. STONETECH® IMPREGNATOR PRO® or STONETECH® BULLETPROOF®) then use STONETECH® KLENZALL™ at its strongest solution of 1 part STONETECH KLENZALL to 2 parts warm water (1:2). Please read and understand the directions for use prior to using as directed.

Dilute concentrated cleaner with warm water according to the following mixing chart:

| Use              | STONETECH KLENZALL™ | Warm Water |
|------------------|---------------------|------------|
| Heavy Duty       | 1 part              | 2 parts    |
| Spray Refill     | 1 part              | 4 parts    |
| light Duty       | 1 part              | 8 parts    |
| Acid neutralizer | 1 part              | 32 parts   |

1. Apply mixed solution with a mop, sponge or sprayer. Avoid applying cleaner on unintended surfaces.
  2. Lightly rub with a scrub brush or floor machine as needed.
  3. Remove solution using a sponge, wet/dry vacuum or damp mop.
  4. Rinse area well with clean water.
  5. Reseal cleaned area with the appropriate STONETECH sealer for your stone and application.
2. If the existing sealer is a topical type (e.g. STONETECH® Semi Gloss Finishing Sealer) it is recommended to use STONETECH® Heavy Duty Coating Stripper. Please read and understand the directions for use prior to using as directed.
    - a. SHAKE WELL BEFORE USING. Do not dilute before applying.
    - b. Wear rubber gloves and eye protection during handling and application to prevent skin and eye contact.
    - c. Liberally apply an even coat over the required area with a paint brush, mop or paint pad. DO NOT APPLY PRODUCT WITH A SPRAYER. Apply a second coat 10 minutes after the first coat to even out the thickness of the application. Immediately remove product from unintended surfaces with a wet cloth to prevent potential damage to those surfaces.
    - d. Application times will vary depending on type of coating being removed. The following are approximate application times:

|                          |                  |
|--------------------------|------------------|
| Sealer, Wax and Varnish  | 30 to 60 minutes |
| Polyurethane and Acrylic | 1 to 2 hours     |
| Epoxy                    | 1 to 2 hours     |

- e. Do not let STONETECH Heavy Duty Coating Stripper dry on the surface. If product starts to dry, add water to keep surface wet.
- f. Agitate surface with a nylon scrub brush or pad after testing a small area first to make sure that brush or pad will not scratch stone. Surface can be wet with water to enable easier removal of coating.
- g. Wipe up residual coating with clean, dry cloths.
- h. Rinse surface well with clean water.
- i. More than one application may be required; repeat steps 3 through 8 when necessary.
- j. Surface traffic may begin 2 hours after removal of coating.

The proper use and application of a high quality STONETECH sealer will provide excellent protection for your stone application and keep your surface looking and performing like you want it to. Please note that reapplication may be necessary from time to time and some maintenance (e.g. cleaning, polishing, etc...) may be required. Sealers are great for preventing absorption of water and oils but will not prevent etching by acidic materials on acid sensitive stone such as polished marble, travertine and others.