




Globally Proven
Construction Solutions

Vapex Waterproofing Membrane

Vapex Membrane is a versatile and easy to use exposed waterproofing membrane that provides excellent flexibility & protection of substrates from water penetration & ultraviolet rays. Ideal for use on all rooftops, terraces & balconies floors, and walls.



FEATURES/BENEFITS

- Easy to install-applies like paint
- Protects substrates from water damage
- Excellent resistance in high & low temperature
- Excellent adhesion on substrates without use of primer
- Able to bridge cracks up to 3mm

MANUFACTURER/DISTRIBUTED BY

LATICRETE Philippines, Inc.
Lot 9A, Manggahan Industrial Park,
Brgy. Manggahan, Sta. Maria,
Bulacan 3022
Telephone: +632 8656 6118
Email: info@laticrete.ph
Internet: ph.laticrete.com

USES

- Interior and exterior
- Rooftops, roof terraces
- Balconies
- Over existing metal roof

STANDARDS/CERTIFICATIONS

- ASTM D2370
- ASTM D2240
- ASTM C836
- ASTM E96
- ASTM E154
- ASTM G154

Suitable Substrates

- Concrete
- Existing steel structures/ roofing
- Concrete & brick masonry
- Cement mortar beds
- Cement plaster
- Gypsum wallboard*
- Exterior glue plywood*
- Ceramic tile & stone**
- Cement terrazzo**
- Cement backer board***

* Interior applications only.

** If skim coated with a LATICRETE latex Thin-Set Mortar.

***Consult cement backer board manufacturer and LATICRETE Technical Department for specific installation recommendations and to verify acceptability for exterior use.

Packaging

Commercial Unit: 25kg pail liquid
(36 commercial units/pallet)

Color: Grey & White

Approximate Coverage

25kg of Vapex Waterproofing Membrane yields approximately 24m² per 2 coats.

Shelf Life

Factory sealed containers of this product are guaranteed to be of first quality for two (2) years if stored at temperatures >0°C and <40°C.

Limitations

- DO NOT bond to particle board, Luan, Masonite, or hardwood surfaces.
- DO NOT use over dynamic expansion joints, structural cracks, or cracks with vertical differential movement.
- DO NOT use over cracks >3mm in width.
- DO NOT use as a vapor barrier (especially in steam rooms).
- DO NOT expose to negative hydrostatic pressure, excessive vapor transmission, rubber solvents or ketones.
- Consult technical service if to be used as a primary waterproofing membrane over occupied space.

Note: Surfaces must be structurally sound, stable, and rigid enough to support ceramic/stone tile, thin brick, and similar finishes. Substrate deflection under all live, dead and impact loads, including concentrated loads, must not exceed $l/360$ for thin bed ceramic tile/brick installations or $l/480$ for thin bed installations where l =span length.

TECHNICAL DATA

Physical Properties

Test	Test Method	Results
Tensile Strength @28 days	ASTM D2370	>1.8N/mm ²
Elongation at break	ASTM D2370	> 500%
Shore Hardness	ASTM D2240	> 60
Crack Bridging	ASTM C836	No cracks@ 2mm
Water Vapor Transmission	ASTM E96	< 20q/m ² .24h
Puncture Resistance	ASTM EI 54	> SOON
QUV Accelerated Weathering	ASTM GI 54	No cracking, blistering & delamination

*Specifications subject to change without notification. Results shown are typical but reflect test procedures used. Actual field performance will depend on the type of tile/stone/brick used, installation methods and site conditions.

Working Properties

Vapex Waterproofing Membrane can be applied using a paint brush, roller, or trowel. Where movement is expected, Anti-Fracture Fabric / reinforcing mesh is recommended to be used to embed within liquid membrane. All areas must have at least two coats to ensure waterproofing capabilities. When using a paint roller, substrate will not show through Vapex Waterproofing Membrane.

INSTALLATION

Surface Preparation

Surface temperature must be 8 - 35°C during application and for 24 hours after installation. All substrates must be structurally sound, clean, and free of dirt, oil, grease, paint, laitance, efflorescence, concrete sealers or curing compounds. Make rough or uneven concrete smooth to a wood float or better finish with a LATICRETE underlayment. Do not level with gypsum or asphalt-based product. Dampen hot, dry surfaces, and sweep off excess water - installation may be made on a damp surface. New concrete slabs shall be damp cured and a minimum of 14 days old before application.

Pre-Treat Cracks, Joints, Coves/ Corners & Backer Board Joints

Fill all substrate cracks, cold joints, and control joint to a smooth finish using a Latex Fortified Thin Set. Alternatively, a liberal coat of Vapex Waterproofing Membrane applied with a paint brush or trowel may be used to fill in non-structural joints and cracks less than 3mm. Apply a liberal coat of Vapex Waterproofing Membrane approximately 200mm wide over substrate cracks, cold joints, and control joints using a paint brush or roller (heavy napped roller cover).

Fill all substrate coves and floor/wall transitions to a smooth finish and changes in plane using a latex fortified thin-set mortar. Alternatively, a liberal coat of Vapex Waterproofing Membrane applied with a paint brush or trowel may be used to fill in cove joints and floor/wall transitions <3mm. Apply a liberal coat of Vapex Waterproofing Membrane approximately 200mm wide over substrate coves and floor/wall transitions using a paint brush or roller (heavy napped roller cover). Embed 150mm Anti-Fracture Fabric (if necessary) and then apply a second coat of Vapex Waterproofing Membrane.

Pre-Treat Drains

Drains must be of the clamping ring type, with weepers and as per ASME A112.6.3. Apply a liberal coat of Vapex Waterproofing Membrane liquid around and over the bottom half of drain clamping ring. Embed 150mm Anti-Fracture Fabric (if necessary) and then apply a second coat of Vapex Waterproofing Membrane. When dry, apply a Latasil™ bead where the Vapex Waterproofing Membrane meets the drain throat. Install the top half of drain clamping ring.

Pre-Treat Penetrations

Allow for a minimum 3mm space between drains, pipes, lights or other penetrations and surrounding ceramic tile, stone, or brick. Pack any gaps around pipes, lights, or other penetrations with a LATICRETE Latex fortified thin-set mortar. Apply a liberal coat of LATICRETE Ener-Shield Waterproofing liquid around penetration opening. Embed 150mm Anti-Fracture Fabric (if necessary) and then apply a second coat of Vapex Waterproofing Membrane. Bring Vapex Waterproofing Membrane up to level of tile or stone. When dry, seal flashing with Latasil.

Priming

The substrate must be sound, clean & free of dust, if not it is strongly recommended to use Admix & Primer. Shake thoroughly before using. Pour, mop, or spray primer onto the surface. Apply an even thickness of primer to the prepared substrate using a bristle broom to ensure the primer is absorbed into the substrate, removing any puddles or thick areas. Allow the primer to dry to a clear film usually 30 - 45 minutes, but less than 3 hours before application of Vapex Waterproofing Membrane.

Note: Keep primed surface clean. Do not allow any foot traffic onto the surface.

Mixing

Use direct from pail.

Application

Allow any pre-treated areas to dry the touch. Apply a liberal coat of Vapex Waterproofing Membrane with brush or roller over substrate including pre-treated areas. Then embed the 150mm wide Anti-Fracture Fabric and allow to bleed through (if necessary). Let topcoat dry to the touch, approximately 1 - 3 hours at 21°C and 50% RH.

Apply the second coat of Vapex Waterproofing Membrane. When the second coat has dried to the touch, inspect the final surface for pinholes, voids, thin spot, or other defects. Use additional Vapex Waterproofing Membrane to seal defects. Provide protection for newly installed membrane, even if covered with a thin bed ceramic tile, stone, or brick installation, against exposure to rain or other water for a minimum of 24 hours at 21°C and 50% RH.

Installing Finishes

Allow Vapex Waterproofing Membrane to dry for 24 hours before ceramic tile, stone or brick may be installed by the thin bed method with a LATICRETE Latex Thin-Set Mortar. Do not use solvent-based adhesives directly on Vapex Waterproofing Membrane.

Expansion Joints

Ceramic tile, stone and brick installations must include expansion at coves, corners, other changes in substrate plane and over any expansion joints in the substrate. Expansion joints in ceramic tile, stone or brickwork are also required at perimeters at restraining surfaces, at penetrations and at the intervals described in the Tile Council of North America (TCNA) Handbook Installation Method EJ171. Use LATICRETE Latasil and backer rod.

Cleaning

Clean tools with water.

AVAILABILITY AND COST

Availability

LATICRETE and LATAPOXY materials are available worldwide.

For distributor information, call:

Telephone: +632 8656 6118

For on-line distributor information, visit LATICRETE at ph.laticrete.com

Cost

Contact a LATICRETE Distributor in your area.

WARRANTY

LATICRETE Philippines Inc. warrants that VAPEX Membrane is free from manufacturing defects and will not break down, deteriorate, or disintegrate under normal usage for a period of one (1) year from date of purchase subject to the terms and conditions stated in Data Sheet.

MAINTENANCE

LATICRETE® and LATAPOXY® grouts require routine cleaning with a neutral pH cleaner (e.g. STONETECH® Stone & Tile Cleaner) and water. All other LATICRETE and LATAPOXY materials require no maintenance, but installation performance and durability may depend on properly maintaining products supplied by other manufacturers.

TECHNICAL SERVICES/CONTACT

Technical Assistance

Information is available by calling:

LATICRETE Philippines, Inc.
Lot 9A, Manggahan Industrial Park,
Brgy. Manggahan, Sta. Maria, Bulacan 3022
Telephone: +632 8656 6118
Email: info@laticrete.ph

Technical and Safety Literature

To acquire technical and safety literature, please visit our website at ph.laticrete.com